

Sport Field Lighting Instructions

Turn lights on:

- Press # to clear the system
- Enter your 5-digit code (see league administrators)
- Enter the appropriate field # (1, 2, 3 or 5)
- Press #
- You should hear a loud “thud” from the electric box as the contacts are made.
- Notes:
 - Light codes will not work until after 1:00pm
 - Lights will not re-light immediately after they are turned off. They need approximately 20 min. to recycle.

Turn Lights off:

- Press # to clear the system
- Enter your 5-digit code
- Enter the appropriate field # (1, 2, 3 or 5)
- Press *
- You should hear a loud “thud” from the electric box as the contacts are separated.
- Notes:
 - For safety, only half of the lights will go off immediately. The rest will remain on for 10 min. to allow safe exit from the field.
 - In order to turn the lights off with a different code than was used to turn them on, you must first go through the “turn on” process above using the new code, and then use the “turn off” process.

Notes:

- The lights will automatically go off at 10:45pm if they are still on. Half the lights will remain on for 10 min. to allow safe exit from the fields.
- If you have problems with the system, please contact a Park Ranger (when on duty)
- Please report all problems to the Parks and Recreation Director: 537-7295